

CHEMICAL REACTIVITY TEST FOR THERMAL STABILITY

D. W. Prokosch
F. Garcia

Lawrence Livermore National Laboratory
University of California, Livermore, California

ABSTRACT

Lawrence Livermore National Laboratory (LLNL) has developed a thermal stability test procedure that is currently being evaluated by the Department of Defense (DOD) Explosives Safety Board as an equivalent alternate test to the DOD Technical Bulletin 700-2 "Thermal Stability Test at 75° C".¹ This procedure will also be submitted for evaluation for acceptance under the similar test specified in the *United Nations Recommendations on the Transport of Dangerous Goods, Tests and Criteria Manual*.² The LLNL Chemical Reactivity Test (CRT) is significantly more severe than the existing "Thermal Stability Test at 750 C" and is also quantitative in nature. It has been approved by the Department of Energy (DOE) Explosives Safety Committee³ as an equivalent alternate thermal stability test and has been in use by LLNL for over 30 years.^{4,5} It is currently used by other DOE and DOD organizations as the standard small-scale safety test for determining thermal stability and material compatibility.

The LLNL CRT is run on a 0.250 gm sample for 22 hours at 120° C rather than the 50 gm sample for 48 hours at 750 C as required for the Thermal Stability Test. Thus the CRT is a much more severe test since it is run at 120° C rather than 750 C. Simple Arrhenius kinetics predict a material decomposition rate of approximately 25 times greater at 120° C than at 75° C. Any material under test that exhibits gas evolution exceeding 4 cc/gm (approximately 0.8 % decomposition) is considered suspect and additional testing and/or evaluation is then performed to determine if the material is thermally unstable.

In addition to the CRT being significantly more severe and quantitative, there are significant other advantages for using the CRT. These include: (1) the increased safety afforded to operating personnel and equipment by using a fraction of the test material, (2) the cost savings associated with reduced sample heating time and the use of less sample material, and (3) the reduced amount of post-test waste produced.

Chemical Reactivity Test for Thermal Stability

1.0 Introduction

The Lawrence Livermore National Laboratory (LLNL) chemical reactivity test (CRT) is a thermal stability test which measures the amount of several gases evolved from an explosive

Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE AUG 1994		2. REPORT TYPE		3. DATES COVERED 00-00-1994 to 00-00-1994	
4. TITLE AND SUBTITLE Chemical Reactivity Test for Thermal Stability				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) University of California, Lawrence Livermore National Laboratory, Livermore, CA, 94551				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited					
13. SUPPLEMENTARY NOTES See also ADM000767. Proceedings of the Twenty-Sixth DoD Explosives Safety Seminar Held in Miami, FL on 16-18 August 1994.					
14. ABSTRACT see report					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT Same as Report (SAR)	18. NUMBER OF PAGES 9	19a. NAME OF RESPONSIBLE PERSON
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified			

sample after it has been exposed to a thermal environment for a period of time. The CRT is used as an alternative test to the Thermal Stability Test at 750 C. The explosive sample may also be mixed with another material to determine mutual compatibility. A measure of the reactivity is obtained when comparing the types and volumes of gases liberated from the mixture with the types and volumes of gases evolved by the individual components of the mixture.

Typically a 0.250 gm sample, under a helium blanket, is immersed in a 120° C bath for 22 hours. A minimum of two runs per sample are made on each material under test. Temperatures and/or times may be changed as required by the characteristics of the particular sample. Helium is used to sweep off any gaseous products of thermal decomposition through a gas chromatograph which has been programmed to analyze for N₂, O₂, Ar, CO, NO, CO₂, and N₂O. The results are given in terms of the sum (excluding Ar) of these volumes expressed as cc/gm.

The CRT is only run on a 0.250 gm sample rather than the ~50-100 gm sample specified by the Thermal Stability Test at 75° C, however, it is a much more severe test since it is run at 120° C rather than 75° C. Simple Arrhenius kinetics predict a material decomposition rate of approximately 25 times greater at 1200 C than at 75° C. PBX-9404 is used as the reference material in this test. It evolves ~1.5 to 2.0 cc of gas per gram of explosive. Any material under test that exhibits gas evolution twice as great as PBX-9404 (4 cc/gm, approximately 0.8% decomposition) is considered suspect and additional tests and/or evaluation may be required to determine if the material is thermally unstable.

The CRT is normally run on an explosive composition as a powder unless it is a paste or a cast/cure PBX. Consolidated materials (pressed pellets) are generally not attempted. However, parallel tests on powders versus consolidated pellets on six explosive materials (see Section 5.0) showed that, except for PETN, there was not a significant difference between powders and consolidated pellets. In the case of PETN, the powder gave about twice the off-gas as pellets, but still less than PBX-9404. Therefore for most materials, either technique will give results applicable to both conditions. The CRT is not generally recommended for materials with high vapor pressures.

2.0 Apparatus and Materials

2.1 Apparatus

- (1) A Hewlett Packard Model 5890 Series II gas chromatograph with a Model 3396 integrator is used to analyze the gas sample. A 20' by 1/8" OD Porapak Q 50-80 mesh molecular sieve is used in the chromatograph. Helium which has been passed through a liquid nitrogen cold trap is used as the carrier gas.
- (2) A tank containing heated silicon brake fluid is used to heat the sample under test. Silicon brake fluid is used because it has low volatility and is thermally

stable. A temperature control unit which heats and circulates the fluid is attached to the tank. Temperature of the bath is maintained up to 120° C by the control unit to within $\pm 1^\circ$ C of the set point.

- (3) Sample holder vessels called "loops" (see Figure 1), which are comprised of the following stainless steel components: a

sample holder with a valve, a diffusion plug (used as a weight),


a diffusion upper spacer, a crucible and a lower spacer. The internal volume of the loop is approximately 17 ml.

- (4) An analytical balance capable of determining sample weight to ± 0.001 gm.
- (5) A vacuum pump and vacuum system with pressure indicator. This system should be capable of evacuation down to approximately 10 millitorr.

2.2 Materials

- (1) A pressurized gas bottle containing small percentages of N₂, NO, N₂O, and CO₂ to be used as a calibration gas.
- (2) A pressurized gas bottle containing ultra pure (99.999%) helium.
- (3) Standard explosives as required. PBX-9404 is used as the reference material. An amount of a specific lot of PBX-9404 is set aside for future use as a standard.

Figure 1. CRT sample holder “loop” assembly. All loop components are made from stainless steel.



3.0 Procedure

3.1 Sample Preparation

- (1) Prepare 2 crucibles with 0.250 gm \pm 0.001 gm of explosive sample. If chemical reactivity/compatibility tests are to be performed, thoroughly mix 0.250 gm of the explosive material with 0.250 gm of the material being tested (also preparing duplicate samples).
- (2) After the 0.250 gm sample is carefully weighed on an analytical balance (0.500 gm mixture for reactivity/compatibility tests), it is then placed into the loop assembly.

3.2 Sample Loop Preparation and Heating

- (1) The loop is then attached to a vacuum rack and evacuated until all outgassing quits. Flush with helium if necessary.
- (2) Backfill the sample loop with 1 atmosphere of helium.
- (3) Remove the sample loop from the vacuum system and place the sample loop into the silicon bath. Note the time the sample loop is placed into the bath.
- (4) At the end of the 22 hour heating cycle, the sample loop is removed from the bath and allowed to come to ambient temperature before running the gas analysis.

3.3 Sample Gas Analysis

- (1) The gas chromatograph is routinely calibrated with a calibration gas containing a known small percentage of each of the gasses being analyzed. In addition, PBX-9404 should be routinely run since it is used as the standard.
- (2) Prepare the gas chromatograph for sample gas analysis. The equipment is turned on and allowed to warm up.
- (3) Information for each sample loop is entered through the chromatograph integrator prior to sample analysis. This should include as much about the material as possible (e.g., material name and any other numbers or letters that will identify it, sample amount, temperature at which it was heated, the present job number, etc.).
- (4) Obtain LN and fill the cold trap to cool the helium purge supply.
- (5) Check helium gas supply regulator and adjust to 60 psi.

- (6) Turn on the CO₂ supply to cool the gas chromatograph. The gas chromatograph takes several minutes to reach its operating temperature of -40° C and takes about 3 minutes to stabilize.
- (7) Connect the sample loop to the vacuum manifold and evacuate the air at the connection.
- (8) When the gas chromatograph is stabilized, the sample loop valve is opened and the gas chromatograph is started.
- (9) After a couple of minutes into the run, the sample loop can be removed and replaced with a new sample. The air must again be evacuated at the connection.
- (10) Once the samples have been run, all sample loop hardware must be cleaned with isopropyl alcohol after each run. In addition, the part of the loop which contains the explosive sample is heated overnight in an oven to drive off any volatile materials.

4.0 Criteria and Method of Assessing Results

4.1 Thermal Stability

A test result is considered positive (i.e., thermally unstable) if ignition or an explosion occurs. If the CRT gas volumes produced are in excess of 4 cc/gm (approximately 0.8% decomposition), additional tests (e.g., decreasing CRT temperature to 100 or 800 C and increasing the time to 48 hours) and/or evaluation may be required to determine if the material is thermally unstable. If the CRT gas volumes produced are less than 4 cc/gm, the material is considered thermally stable. For reference purposes, 1 cc of evolved gas/gm of explosive represents about 0.2% decomposition.⁶

4.2 Chemical Reactivity/Compatibility for a Mixture

- (1) If the CRT gas volume of the mixture is equal to or less than the sum of the individual components, there is no evidence of chemical reactivity and the mixture is considered chemically compatible and unreactive.
- (2) If the CRT gas volume of the mixture is significantly greater than the sum of the individual components, there is evidence of chemical reactivity and the mixture should be considered incompatible on the basis of this test. Other testing such as differential scanning calorimetry (DSC) and /or analysis is required. Generally, total gas volumes of the mixture that are between 1.0 and 1.5 cc/gm are moderately reactive and the materials are considered incompatible.

Note: These numbers are only to be used as general guidelines and are not to

be used as defining criteria. All data should be reviewed by a qualified person, who has a good understanding of what the presence of the various decomposition products (including at various temperatures) really means. The sum of the gas products of the individual components should be carefully compared to the total gas products of the mixture to determine where the differences occur and if they are significant.

5.0 Examples of Results

Typical Individual Gas Evolution Results (cc/0.250 gm at 120° C for 22 hours)⁷

<u>Explosive Material</u>	<u>N₂</u>	<u>O₂</u>	<u>CO</u>	<u>NO</u>	<u>CO₂</u>	<u>N₂O</u>	<u>Total</u>
PETN (powder)	0.046	0	0.038	0.080	0.131	0.014	0.309
PETN (pellet)	0.013	0	0.011	0.028	0.069	0.005	0.126
Comp B (powder)	0.011	0	0	0.024	0.039	0.018	0.092
Comp B (pellet)	0.014	0	0	0.021	0.018	0.020	0.073
LX-14 (powder)	0	0	0	0	0.053	0.006	0.059
LX-14 (pellet)	0	0	0	0.004	0.016	0.006	0.026
LX-17 (powder)	0	0	0	0	0.023	0	0.023
LX-17 (pellet)	0	0	0	0	0.042	0	0.042
PBX-9404 (powder)	0.020	0	0.039	0.244	0.137	0.023	0.463
PBX-9404 (pellet)	0.056	0	0.049	0.171	0.198	0.039	0.513

Typical Individual Gas Evolution Results (cc/0.250 gm at 120° C for 22 hours)⁷

Composition of Explosive Material Compounds

PETN	Pentaerythrol tetranitrate
Comp B	63% RDX (trinitro-triazocyclohexane) 36% TNT (trinitrotoluene) 1% Wax
LX-14	95.5% HMX (tetranitro-tetrazo-cyclooctane) 4.5% Estane 5702-F1 (hydrocarbon polymer binder)
LX-17	92.5% TATB (triaminotrinitrobenzene) 7.5% Kel-F 800 (fluoropolymer binder)
PBX-9404	94% HMX 2.9% Nitrocellulose 3.0% Tris- β -chloroethyl-phosphate plasticizer (CEF) 0.1% Diphenylamine

Composition of Explosive Material Compounds

6.0 Acknowledgments

The authors would like to thank Hy Golopol and Frank Helm for their technical review and input to this acceptance procedure.

7.0 References

1. Department of Defense, "Department of Defense Explosives Hazard Classification Procedures," Army TB 700-2, Navy NAVSEAINST 8020.8A, Air Force TO IIA-1-47, Defense Logistics Agency DLAR 8220.1, December 1989.
2. *United Nations Recommendations on the Transport of Dangerous Goods, Tests and Criteria*, ST/SG/AC.10/11, Second Edition, 1990.
3. Department of Energy, 28th Meeting Minutes of the DOE Explosives Safety Committee, Los Alamos, New Mexico, June 1993.
4. J. W. Frazer, "A New Explosives Compatibility Test", UCRL-6244, 1960.

- 5 J. W. Frazer and K. Ernst, "Chemical Reactivity Testing of Explosives", *EXFLOSIVSTOFF nR.*, pp. 4-9, 1964.
- 6 Lawrence Livermore National Laboratory, *LLNL Explosives Handbook*, Livermore, California, UCRL-52997 Change 2, page 6-84, January 1985.
- 7 Lawrence Livermore National Laboratory CRT Record, Job No. 1803, April 7, 1992.

Work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract No. W-7405-Eng-48.

DISCLAIMER

This document was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial products, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of the author expressed herein does not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.